

THE PLATINUM PACKAGING GROUP

PLAT*Machinery* Table Top Tray Sealers HSTT SEALING MACHINES

Error Code	Error Message	Possible Cause	Solution
E00	Temperature Error	Wire Error	1. Call Tech
E01	Temperature Error	Temp. Too High	1. Reboot 2. Lower Temp. 3. Call Tech
E02	Cylinder Not Working	No Air Supply	1. Check Compressor To See If Air Is On 2. Call Tech
E03	Lower Mold Error	Error Appears Right After Power On	1. Check Micro Switch 2. Check for Obstructions 3. Call Tech
E04	Wrong Input for Rewind Roller	Wrong Setting Adjust Menu	1. Clean Eye-Mark Sensor 2. Call tech
E05	Lower Mold Error	No Air Pressure Out of Alignment	1. Check Micro Switch 2. Call Tech
E06	Upper Mold Error	No Air Pressure Out Of Alignment	1. Check Compressor 2. Check Mold Alignment 3. Call Tech
E07	Safety Door Error	Safety Door Touched	1. Wait for Switch to Turn Off 2. Call Tech
E09	Cylinder Sensor Error	Out of Position	1. Check Air Pressure 2. Call Tech
E19	P.C. Board Error	P.C. Board Error	1. Call Tech *Must Change P.C. Board



HSTT 4 on a Stainless Steel Table. (Table Sold Separately)

THE PLATINUM PACKAGING GROUP

tel: (562) 630-6700

7627 Somerset Blvd., Paramount, CA 90723

TO PLACE ORDERS:
sales@platinumpkggroup.com

FOR MORE INFORMATION:
www.platinumpkggroup.com

QUESTIONS:
information@platinumpkggroup.com